



Support: API | 🔀 Manual [DE] | 🔁 Fact Sheet [DE] | 🔀 Fact Sheet [EN] | 🔁 Installation Guide [DE] | 🔀 Installation Guide [EN] |

Professional navigation on notebook, Car-PC or PDA with door-to-door routing and Touchscreen optimized interface. Audio navigation prompts are combined with a clear map display on the PC.

New in Version 10.5 (26.10.2018):

- Map data 2018.2N

New in Version 10.0 (21.11.2017):

- Bugfixes
- Map data 2017.2N

New in Version 9.0 (16.11.2015):

- Bugfixes

- Map data 2015.2N

New in Version 8.5 (16.10.2014):

139.00 EUR incl. 19% VAT, plus shipping

- TMC support !
- 2D/3D view !
- Speech !
- Map&Guide Fleet Navigator !



- GLONASS-GPS-support
- Economic avoidance of toll for Germany and Austria
- Map data 2014.2N

New in Version 8.0 (25.11.2013):

- route planning with approximate stop-off points improved (fuzzy via)
- Map data 2013.2N

New in Version 7.5 (30.10.2012):

- due to the intelligent self-learning mode (ETA), time is calcula-ted on the basis of individual driving behaviour, resulting in a more accu-rate calculation of the time of arrival.

- route planning with approximate stop-off points (fuzzy via)
- announcement of navigation instructions in off-road mode
- announcement of texts with Text2Speech
- display of other vehicles (bud-dies) with geofencing alerts
- only a few tags are sufficient to influence the routes.
- Map data 2012.2N

New in Version 7.0 (21.11.2011):

- Improved graphical design
- Option to "Avoid toll roads" [only PC/PDA]
- Self-learning vehicle profile [only PC/PDA]
- Faster address-search
- Map data 2011.2N

Basic functions

Mobile navigation is a popular alternative to an expensive installation. map&guide fleet navigator provides:

- Door-to-door cross-border navigation
- Intuitive, easy operation
- Precise visual cues and spoken instructions
- 2D and 3D navigation using map&guide clear, intuitive maps
- Proven, professional map&guide routing and navigation
- Extrapolated positioning in tunnels

• Dynamic navigation: The latest TMC information is received on a TMC receiver free of charge and used to update the route while on the road.

• map&guide fleet navigator supports the following languages: German, English, French, Dutch, Italian, Spanish, Portuguese, Danish, Norwegian, Swedish, Polish, Czech, Slovak, Slovenian, Hungarian, Romanian, Turkish, Russian, Bulgarian

- Auto-Smartzoom for optimum map information when approaching a manoeuvre
- Automatically switches between day and night view
- · Speed warning limits also for trucks in many countries
- Text2Speech
- Coordinates input
- Global search for POIs
- Realistic motorway signs and junction views

Connected navigation

With map&guide fleet navigator it is possible to control the navigation of your service employees' cars from your control center: Order files (RC-Interface) and interfaces in C and C# (RI-Interface) enable communication between map&guide fleet navigator and a secondary software which establishes communication with the control center. These functions are used to:

- send stop-off points as address from the control centre to the navigation
- request GPS positions from the navigation and make them available to third-party applications
- start and end mobile navigation
- transfer and display messages to the navigation
- Guided navigation: Transfer of entire route navigation
- · Show other vehicles (buddies) via interface

One fleet - various vehicle profiles

Create different vehicle profiles for the various vehicles in your fleet – this ensures that navigation is tailored to the vehicle. When creating vehicle profiles for cars and trucks with map&guide fleet navigator the following criteria can be taken into account:

- Speed profile
- Avoiding motorways or ferries
- For cars: Optimisation of route in terms of economy or time



• For trucks: Avoiding smaller streets (bypasses), turning, residential areas

Supported operating systems

- Microsoft Windows Mobile 2003 for Pocket PC (incl Second Edition)
- Microsoft Windows Mobile 5,6 (inkl. Phone-Edition)
- Microsoft Windows 2000, Windows XP, Windows Vista, Windows 7, Windows 8

Included maps :

- Central Europe City (D,A,CH)
- Major road network in Europe

Scope of Supply :

- Fleet Navigator (includes PDA/PC program and all maps)

Screenshot-gallery with Step-by-Step introduction (Version 7)



Manuals

German English French Dutch

Developer-API

Remote Control Remote Interface





